

4.3.5 Configure NTFS Permissions

Your Performance

Your Score: 0 of 2 (0%)

Elapsed Time: 15 seconds

Pass Status: **Not Passed**

Required Score: 100%

Task Summary

Required Actions

✗ Edit permissions for the D:\Marketing Data folder [Hide Details](#)

- ☐ Disable permission inheritance for the folder
- ☐ Convert existing permissions
- ☐ Do not assign permissions to the Users group
- ☐ Add the Marketing group to the access control list
- ☐ Assign Marketing Full Control permissions
- ☐ Do not assign explicit permissions to other users or groups

✗ Edit permissions for the D:\Research Data folder [Hide Details](#)

- ☐ Disable permission inheritance for the folder
- ☐ Convert existing permissions
- ☐ Do not assign permissions to the Users group
- ☐ Add the Research group to the access control list
- ☐ Assign Research Full Control permissions
- ☐ Do not assign explicit permissions to other users or groups

Explanation

Complete this lab as follows:

1. Open the Data (D:) drive.
 - a. From the Windows taskbar, select **File Explorer**.
 - b. From the left pane, expand and select **This PC > Data (D:)**.
2. Disable inheritance and convert inherited permissions to explicit permissions.
 - a. From the right pane, right-click the applicable **folder** and then select **Properties**.
 - b. Select the **Security** tab.
 - c. Select **Advanced** to modify inherited permissions.
 - d. Select **Disable inheritance** to prevent inherited permissions.
 - e. Select **Convert inherited permissions into explicit permissions on this object**.
3. Remove the Users group from the access control list.
 - a. In *Permission entries*, select **Users**.
 - b. Select **Remove** to remove the group from the access control list.
 - c. Select **OK**.
4. Add a new group to the access control list and allow Full Control.
 - a. Select **Edit** to add a group to the access control list.
 - b. Select **Add**.
 - c. Enter the **name** of the group you want to add and then select **Check Names**.

- d. Select **OK**.
 - e. With the newly added group selected, under the Allow column, select **Full control** and then select **OK**.
 - f. Select **OK** to close the properties dialog.
5. Repeat steps 2 - 4 to modify the permissions for the additional folder.

Copyright © 2022 TestOut Corporation All rights reserved.